EARTHWISEUSE & CARE 18 INCH SNOW SHOVEL

MODEL: SN-001

ASSEMBLY:

ENSURE ALL CONNECTIONS AND BOLTS ARE TIGHTENED BEFORE USE

- Insert the plastic proprietary connector tip of the lower shaft into the shaft opening on the upper edge of the shovel blade.
- Depress the lower section of the shaft firmly into the shaft opening to permanently secure the lower section of the shaft to the blade.
- Slide the upper section of the shaft into the lower section and secure the two pieces with the bolt, washer and nut provided.

FOR QUESTIONS OR WARRANTY CLAIMS CONTACT RADIUS TOOLS AT radiusgarden.com or call Toll Free 1-800-633-1501

1 YEAR LIMITED WARRANTY

